

The level of complexity of the steps to follow for factory setting restoration was created in order to protect it against the accidental start of the restoration procedure.



## Restoring method with power supply sequence for the devices: *K-SMRT*

- Prepare the stopwatch for precise timing.
- Disconnect the supply from the controller.
- Connect the supply for exactly 5 seconds. Disconnect the supply for a few seconds.
- Connect the supply for exactly 10 seconds. Disconnect the supply for a few seconds.
- Connect the supply for exactly 15 seconds. Disconnect the power supply for a few seconds.
- Connect the power supply: the diode will blink for 3 seconds (if the device is equipped with it), the module will restart automatically and all the settings will obtain their factory values.

